

7. IN AREAS SUBJECT TO SURFACE AND AIR MOVEMENT OF DUST, WHERE ON-SITE OR OFF-SITE DAMAGE IS LIKELY TO OCCUR, ONE OR MORE OF THE FOLLOWING PREVENTIVE MEASURES SHALL BE TAKEN FOR DUST CONTROL:
 - A. MINIMIZE THE PERIOD OF SOIL EXPOSURE THROUGH THE USE OF TEMPORARY GROUND COVER AND OTHER TEMPORARY STABILIZATION PRACTICES.
 - B. SPRINKLE THE SITE WITH WATER UNTIL SURFACE IS WET. REPEAT AS NEEDED. PROVIDE A STABILIZED CONSTRUCTION ENTRANCE TO PREVENT CARRY OUT OF SEDIMENT OFF SITE.
 - C. SPRAY EXPOSED SOIL AREAS WITH DUST PALLIATIVE. USED OIL IS STRICTLY PROHIBITED FOR USE AS A PALLIATIVE.
8. TEMPORARY SEEDING SHALL BE PLACED ON EXPOSED SURFACES THAT WILL NOT BE BROUGHT TO FINAL GRADING OR PERMANENT COVER TREATMENT OR VEGETATION WITHIN 7 DAYS OF THE EXPOSURE TO REDUCE EROSION AND SEDIMENTATION BY STABILIZING EXPOSED SOILS. DURING THE TIME PERIOD OCTOBER 1 THROUGH APRIL 30, NO SOILS SHALL BE EXPOSED FOR MORE THAN 2 DAYS. SEEDED AREAS SHALL BE CHECKED REGULARLY TO ASSURE A GOOD STAND OF GRASS IS BEING MAINTAINED. AREAS THAT FAIL TO ESTABLISH VEGETATION COVER ADEQUATE TO PREVENT SLOPE EROSION WILL BE RESEEDED AS SOON AS SUCH AREAS ARE IDENTIFIED.
9. EROSION CONTROL NETS AND BLANKETS SHALL BE INSTALLED ON EXPOSED SLOPES 2H:1V OR GREATER AND/OR ON EXPOSED SLOPES WITH MORE THAN 10 FEET OF VERTICAL RELIEF.
10. ALL PESTICIDES, PETROLEUM PRODUCTS, CHEMICALS OR OTHER POTENTIAL POLLUTANTS SHALL BE ADMINISTERED RESPONSIBILITY WITH DISPOSAL AND SPILLS HANDLED AS SPECIFIED IN THE STORMWATER MANAGEMENT MANUAL FOR WESTERN WASHINGTON, VOLUME II – CONSTRUCTION STORMWATER POLLUTION PREVENTION AND IN ACCORDANCE WITH ALL LOCAL, STATE AND FEDERAL REQUIREMENTS.
11. ALL TEMPORARY, PERMANENT, WET AREA, BIOFILTRATION, AND HYDROSEEDING SHALL BE IN ACCORDANCE WITH BMP C120: TEMPORARY AND PERMANENT SEEDING AS NOTED IN THE STORMWATER MANAGEMENT MANUAL FOR WESTERN WASHINGTON, VOLUME II – CONSTRUCTION STORMWATER POLLUTION PREVENTION. SEEDING SHALL BE APPLIED AT A RATE OF 120 LBS/ACRE.
12. CLEARING LIMITS AND WORK AREA LIMITS SHALL BE DELINEATED AND MARKED. DO NOT DISTURB MORE AREA THAN NEEDED FOR CONSTRUCTION REQUIREMENTS.
13. ALL SENSITIVE OR CRITICAL AREAS (WETLANDS, STEEP SLOPES, NATURAL WATERWAYS, ETC.) AND BUFFERS SHALL BE CLEARLY DELINEATED, MARKED, AND PROTECTED FROM CONSTRUCTION ACTIVITIES.
14. DEWATERING DEVICES MUST DISCHARGE INTO A SEDIMENT TRAP OR POND. THERE SHALL BE NO DISCHARGE TO A PAVED STREET OR STORMWATER COLLECTION SYSTEM WITHOUT FIRST REMOVING SEDIMENT.
15. ALL INCOMPLETE MANHOLES AND OTHER DROP INLETS SHALL BE PROTECTED WITH A SILT-SAVER FRAME AND FILTER ASSEMBLY AS AVAILABLE FROM CSI GEOSYNTHETICS (800)426-7976 OR AN APPROVED EQUAL.